

AFTER LANDING – PARKING – SECURING THE A/C



PF

PNF

1.a. AFTER LANDING


Depending on the taxi position :

ANNOUNCE....."LANDING LIGHTS"

LAND LIGHTS.....RETRACT

GRND SPLRS.....DISARM

STROBE.....AUTO




Signal for PNF actions

➤ Observe the ECAM MEMO :

GND SPLRS ARMED
SEAT BELTS
NO SMOKING

LDG LT





SEAT BELTS
NO SMOKING




PF


PNF

1.b. AFTER LANDING

- 1- RADAR.....OFF/STBY
- 2- PREDICTIVE WINDSHEAR.....OFF
- 3- ENG MODE SEL.....NORM
- 4- FLAPS.....RETRACT 
- 5- { TCAS MODE SEL.....STBY
ATC.....AS RQRD 
- 6- APU.....START
- 7- ANTI ICE.....AS RQRD



➤ Observe the **ECAM MEMO** :



PF

PNF

1.c. AFTER LANDING

BRAKE TEMP.....CHECK

AFTER LDG C/L

➤ Brake temperature Limitations :



➤ Use of brake fans :



PF

PNF

2.a. PARKING

PARKING BRK ACCU PRESS.....CHECK

PARKING BRK.....ON 

ENG MASTER 1 & 2.....OFF 

GROUND CONTACT.....ESTABLISH

BEACONOFF

SEAT BELTS.....OFF

ANTI - ICE.....OFF

APU BLEED.....ON 

SLIDE DISARMED.....CHECK

ELAPSED TIME.....STOP

FUEL PUMPS.....OFF


ATC.....STBY

IRS PERFORMANCE.....CHECK 


STATUS.....CHECK 

➤ Consider « GROUND OPERATIONS IN HEAVY RAIN », refer to FCOM 3.04.30

➤ To stabilize engine hot section temperature :



➤ ECAM SD auto - switching (when last Engine is shut down)



➤ Observe the ECAM MEMO :



PF

PNF

2.b. PARKING

PARKING BRK.....AS RQRD

BRAKE FAN.....OFF


Dus.....DIM

Dus.....DIM

PARKING C/L

REPORT SEVERE ICING CONDITIONS


" BRAKES HOT "



Release parking brakes
after chocks are in place

If operational conditions permits (no slippery tarmac).

Parking with a flat tire on
the nose gear



Keep the brakes ON

PF

PNF


3. SECURING THE AIRCRAFT

PARKING BRK.....CHECK ON
 ADIRS (1+2+3).....OFF


OXY CREW SUPPLY.....OFF
 EXTERIOR LIGHTS.....OFF
 MAINT BUS.....AS RQRD ⓘ
 APU BLEED.....OFF
 APU MASTER SW.....OFF
 EMER EXIT LIGHT.....OFF
 NO SMOKING.....OFF
 EXT PWR.....AS RQRD
 BAT 1 & 2.....OFF

SECURING THE AIRCRAFT C/L


➤ To ensure the ADIRS memorize the last data:



➤ Observe the ECAM MEMO :



➤ To prevent smoke entering the cabin during next start :




PF



PNF


1.b. AFTER LANDING

Icing conditions
Slush or snow on the runway



Wait until engine shutdown and ground confirmation that flaps & slats are cleared of obstructing ice

- 1- RADAR.....OFF/STBY
- 2- PREDICTIVE WINDSHEAR.....OFF
- 3- ENG MODE SEL.....NORM
- 4- FLAPS.....RETRACT 
- 5- { TCAS MODE SEL.....STBY
ATC.....AS RQRD 
- 6- APU.....START
- 7- ANTI ICE.....AS RQRD





➤ Observe the ECAM MEMO :


SEAT BELTS
NO SMOKING

PRED W/S OFF
TCAS STBY
APU AVAIL

1.b. AFTER LANDING

Depending on local regulations, ATC transponder may be operated in mode S

- 1- RADAR.....OFF/STBY
- 2- PREDICTIVE WINDSHEAR.....OFF
- 3- ENG MODE SEL.....NORM
- 4- FLAPS.....RETRACT 
- 5- { TCAS MODE SEL.....STBY
ATC.....AS RQRD 
- 6- APU.....START
- 7- ANTI ICE.....AS RQRD



➤ Observe the **ECAM MEMO** :

SEAT BELTS
NO SMOKING

PRED W/S OFF
TCAS STBY
APU AVAIL

USE OF BRAKE FANS

To avoid brake oxidation


Select brake fans

- just before stopping at the gate (short taxi)
- OR
- 5 min after landing (long taxi)


Short turnaround time

Use of brake fans without oxidation consideration

➤ Observe the ECAM memo if the brake fans are selected



➤ Select brake fans as soon as a green arc appears (temperature > 100°C)



PF

PNF

2.a. PARKING

PARKING BRK ACCU PRESS.....CHECK

PARKING BRK.....ON 

ENG MASTER 1 & 2.....OFF 

GROUND CONTACT.....ESTABLISH

BEACONOFF

Above 500 °C, parking brake application should be avoided, unless operationally necessary.

SEAT BELTS.....OFF

ANTI - ICE.....OFF

APU BLEED.....ON 

SLIDE DISARMED.....CHECK

ELAPSED TIME.....STOP

FUEL PUMPS.....OFF


ATC.....STBY

IRS PERFORMANCE.....CHECK 


STATUS.....CHECK 

➤ Consider « GROUND OPERATIONS IN HEAVY RAIN », refer to FCOM 3.04.30

➤ To stabilize engine hot section temperature :



➤ ECAM SD auto - switching (when last Engine is shut down)



➤ Observe the ECAM MEMO :



PF

PNF

2.a. PARKING

PARKING BRK ACCU PRESS.....CHECK

PARKING BRK.....ON 

ENG MASTER 1 & 2.....OFF 

GROUND CONTACT.....ESTABLISH

BEACONOFF

Switch ON the APU BLEED as later as possible to avoid ingestion of exhaust gases from the engines.

SEAT BELTS.....OFF

ANTI - ICE.....OFF

APU BLEED.....ON 

SLIDE DISARMED.....CHECK

ELAPSED TIME.....STOP

FUEL PUMPS.....OFF


ATC.....STBY

IRS PERFORMANCE.....CHECK 


STATUS.....CHECK 

- Consider « GROUND OPERATIONS IN HEAVY RAIN », refer to FCOM 3.04.30

- To stabilize engine hot section temperature :



- ECAM SD auto - switching (when last Engine is shut down)



- Observe the ECAM MEMO :



PF

PNF

2.a. PARKING

PARKING BRK ACCU PRESS.....CHECK


ANTI - ICE.....OFF

PARKING BRK.....ON 

APU BLEED.....ON 

ENG MASTER 1 & 2.....OFF 

SLIDE DISARMED.....CHECK




IRS PERFORMANCE



➤ Drift check: → POSITION MONITOR page

Check that the drift is in the acceptable margins defined in Fcom 3.03.25



➤ Residual ground speed check:

**Ground Speed ≥ 15 kts
&
Excessive deviation occurred
after 2 consecutive flights**

OR

Ground Speed ≥ 21 kts

Consider IR as failed

PF

PNF

2.a. PARKING

PARKING BRK ACCU PRESS.....CHECK

PARKING BRK.....ON 

ENG MASTER 1 & 2.....OFF 

GROUND CONTACT.....ESTABLISH

BEACONOFF

SEAT BELTS.....OFF

ANTI - ICE.....OFF

APU BLEED.....ON 

SLIDE DISARMED.....CHECK

ELAPSED TIME.....STOP

FUEL PUMPS.....OFF

ATC.....STBY

IRS PERFORMANCE.....CHECK 

STATUS.....CHECK 

If maintenance status messages are displayed:

- ***At transit : disregard, unless AIR BLEED.***
- ***At main base or airport with repairs available: report for maintenance analysis.***

MAINTENANCE BUS SETTING



Should electrical power be required for the crew or servicing personnel, consider setting the overhead MAINT BUS switch (in the forward cabin) to the ON position, prior to setting aircraft power to off.

